
KitchenAid_®

OVEN PARTS

For Models:KEBS277SSS03 (Stainless)

27" BUILT-IN ELECTRIC DOUBLE OVEN THERMAL CONVECTION



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


OVEN PARTS

For Models:KEBS277SSS03 (Stainless)

Illus No.	. Part No.	DESCRIPTION	Illus No.		DESCRIPTION	Illus No.	. Part No.	DESCRIPTION
2 3	W10220954 W10220955 8304335 9762761 W10065852	Instructions Use & Care Guide Tech Sheet English French Easy Set Guide Safer Cooking Tips English French Bracket, Base Hinge Receiver	on on ons on ons on ons are Guide eet	W10009940 W10169757 A400832 A8304629 A8304494 A449040 A449154 A451477 A450038	Oven Light Assembly Bulb, Light Screw (2) Frame, Front Gasket, Door Screw Screw Screw Screw Support, Insulation Screw (2) Mounting Rail,Side	26 27 28 29 30 31 32 33 34 35 36 37	8304452 W10131825 8303724 8303772 8304478 8303517 W10216231 4448444	Sensor Vent, Center Base, Chassis Retainer, Gasket Cover, Back Trim, Bottom Vent Grommet, Mounting Rail Screw (12)
4 5 6 7 8 9	4455605 W10105790 8303829	Left Bumper, Door (2) Exhaust, Vent Slope Divider, Center Vent Top Chassis Screw	22 23 24 25	4449743 4449748	Latch, Mortorized Screw	INS	NOT ILL SULATION 8303966	VING PARTS LUSTRATED Insulation, Wrap Insulation, Back

CONTROL PANEL PARTS


For Models:KEBS277SSS03 (Stainless)



No.	No.	DESCRIPTION
1 2	W10216220 8303687	Panel, Control Support, Appliance
_		Manager
4	8304332	Keyboard, Glass Touch
5	W10172472	
6		Backer, Control
7	8303887	Bracket,
		Enclosure (2)
8	4449154	Screw
9	3400832	Screw
10	W10119142	Appliance Manager
11	8304441	Resistor, Drop

OVEN DOOR PARTS


For Models:KEBS277SSS03 (Stainless)




Illus No.	. Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION
1		Bumper, Door	7		Glass, Inner	12	W10237352	Door Glass,
2	W10174288	Hinge, Door (2)	8	4449743	Screw			Assembly
3	3196183	Screw	9		Cover, Hinge			Lower Includes #17
4	8304580BL	Vent, Door Top		W10137044	Right		W10237353	Door Glass,
5		Bracket, Door		W10137043	Left			Assembly
	8304377	•	10	8304523	Seal			Upper No Badge
	8304378	Left	11	8304361BL	Bracket, Handle	13	8303775SS	Door Handle
6	8303738BL	Door Liner				15	8303745BL	Frame, Door Side(2)
_						16		Door, Top Bracket
						17	8304603SS	

INTERNAL OVEN PARTS For Models: KEBS277SSS03

For Models:KEBS277SSS03 (Stainless)






Illus. No.	Part No.	DESCRIPTION
1	8304602	Element, Broil Shield
2	9760774	Element, Broil
3	4449154	
4	8303842	Rack, Oven
6	9760768	Element, Bake
7	4455036	Tray, Bake
8	4450039	Cover, Bake Tray
9	4449809	Screw
10	8304422BU	Cover, Fan
11	9760769	Element
		Convection
12	W10116351	Blade, Fan
13	W10116349	Nut
14	W10116228	Fan, Convection
15	9755543	Jack, Meat Probe
16	9755542	Probe, Meat
17	9755547	Washer, Lock
18	9755546	Nut, Hidden

TOP VENTING PARTS

For Models:KEBS277SSS03 (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9752759	Relay (2)
2		Duct, Air Outlet
3	4449809	•
4	8303972	Blower, 60mm
6	8285593	
7	W10111628	
		Transformer
8	4450118	Nut
9	4449868	Block, Terminal
10	3400080	Screw
11	8303722	Vent, Control
		Panel
12		Side, Control Top
	8303518	
	8304255	Left
13	8303520	Back, Control
14	8304220	Cover, Top
15	7103P027-60	Nut (3)

OPTIONAL PARTS (NOT INCLUDED)

For Models:KEBS277SSS03 (Stainless)

Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White 261869 Cord Brown 72032 Black

PAINT, SPRAY

350930 White 261900 Citrine White 830864 Black

ADHESIVE

591014 Adhesive Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)

WIRING HARNESS PARTS

W10143473 Harness, Latch
W10155291 Connector, Flex
W10171563 Harness, Main
8304051 Harness,
Communication
8304439 Conduit, Double
4450800 Screw,Ground
4452260 Spacer, Foam

Miscellaneous

4448950 Screw, Install (4) 98997 Clip